



HRD20 spare parts list

From serial number 3195



HRD20 spare parts list – with external air supply

From serial number 3195



Parts marked are removed and the kit for external air supply is added

Part No. 9992399

HRD20 spare parts list

From serial number 3195

Pos.	Part No.	Description	Pcs.
-	9932077	Seal kit	1
-	4141685	Tailhose set	1
		<i>Incl. quick-release couplings</i>	
-	7401141	Q.R. coupling 1/2" BSP male	1
-	7401142	Q.R. coupling 1/2" BSP female	1
1	9932183	Inner tube	1
2	9932184	Piston	1
3	9931841	Stud bolt	2
4	9932185	Cylinder	1
5	9932186	Hammer piston	1
6	9931844	Piston ring	1
7	9931845	Compressor cylinder	1
8	9932187	Bushing	1
9	9932188	Coller	1
10	9932189	Motor block	1
11	9931849	Dial knob	1
12	9931850	Valve guide	1
13	9931851	Selector valve	1
14	9931783	Washer	1
15	9931852	Internal shaft	1
16	9931853	Idling gear	1
17	9931854	Drive gear	1
18	9932241	Gear housing	1
19	9931856	Drill stay	1
20	9931857	Seat packing	1
21	9932242	Valve seat	1
22	9931859	Packing	1
23	9932190	Cleaner case	1
24	9931861	Packing	1
25	9931862	Element	1
26	9931863	Filter	1
27	9932191	Filter cover	1
28	9931865	Retainer	4
29	9931866	Lead valve	4
30	9931784	Air seal	1
31	9931867	Cap nut	1
32	9932192	Cap bolt	1
33	9931869	Lid	1

Pos.	Part No.	Description	Pcs.
34	9931870	Diaphragm	1
35	9931871	Shell	1
36	9931872	Handle	2
37	9931873	Valve housing	1
38	9931874	Trigger lever	1
39	8931299	ID-tag	1
40	9931875	Valve rod	1
41	9932193	Valve guide	1
42	9931877	Control valve	1
43	9931878	Nut	2
44	9931879	O-ring	1
45	9931880	Nut	1
46	9931881	Spring washer	1
47	9932194	Screw	1
48	9932195	Seal washer	2
49	9932196	Cap nut	1
50	9931782	Bushing	2
51	9932198	U-cup packing	1
52	9932199	Dust seal	1
53	9931785	Seal	1
54	9932205	Spring	1
55	7521017	Seal ring 3/8"	2
56	9931887	Washer	2
57	9931888	Washer	2
58	9931889	Key	1
59	9931890	Steel ball	2
60	9931891	Roller	2
61	9931892	Pipe plug 1/8"	7
62	9931893	Pipe plug 1/16"	6
63	9931786	O-ring	1
64	9931894	O-ring	1
65	9931895	O-ring	1
66	9931896	O-ring	2
67	9931897	O-ring	1
68	9931898	O-ring	1
69	9931899	O-ring	1
70	9931787	O-ring	2

Pos.	Part No.	Description	Pcs.
71	9932200	O-ring	1
72	9931901	O-ring	3
73	9931902	O-ring	1
74	9931903	Back up ring	1
75	9931904	Pin 2.5x8	1
76	9931905	Pin 5x36	1
77	9931906	Pin 6x20	2
78	9931907	Spring	1
79	9931908	Screw	1
80	9931909	Screw	1
87	9931910	Bolt 12x50	2
88	9931911	Bolt 10x25	4
89	9931912	Bolt 6x20	4
90	9931913	Washer	4
91	9931881	Spring washer	8
92	9931914	Screw	8
93	9932227	M6 orifice	1
94	9932201	Bushing	1
95	9931781	Bushing	2
96	9932202	Bush	1
97	9932203	O-ring	1
98	9932204	Expander	3
99	9931915	Back up ring	1
100	9932206	Guard	1
101	9932207	Bolt	4
102	9932208	Fastener	1
103	9932209	Screw	2
104	9932210	Washer	2
105	9932226	Plate nut	1
A1	9932212	Accumulator assy	1
A2	9932213	Compressor assy	1
A3	9932214	Valve body assy	1
A4	9932215	Cylinder assy	1
A5	9932216	Gear housing assy	1
A6	9932217	Motor block assy	1
A7	9932218	Bush assy	1